



**GREENFIELD  
WATER SOLUTIONS**

## **AQUAFLEX INSTALL ADDENDUM**



- 1. It is imperative that your installer read the entire AquaFlex manual and this addendum before commencing with the installation process.**
2. Your AquaFlex and copper by-pass harness assembly will arrive In one box.
3. Your second box will contain your Copper Vortexer and NaturalSof

4. After having installed the AquaFlex with the copper by-pass assembly, the Copper Vortexer will be attached onto the **inlet** of the by-pass assembly and the NaturalSoft descaler will be attached onto the **outlet** of the by-pass assembly.
5. After the system has been installed and plumbed into the main water supply, install only the GAC bulk filter into stage 2, leaving all other filter housings empty for the purpose of flushing fines out of the filter. After 5 minutes of flushing, the other filters can be installed and the entire system flushed once more for 5 minutes.
6. Filter Installation Order:  
Stage 1: 20 Micron Sediment filter  
Stage 2: Pentek GAC Filter  
Stage 3: Pentek Iron Filter  
Stage 4: Pentek FloPlus .5 micron Filter

#### **INLINE VORTEXER TIPS**

- Installs onto any water supply line up to 1”
- Outfitted with either 3/4” or 1” threaded end fittings.
- Bi-directional flow
- Install vertically or horizontally
- Maintenance free
- Never needs replacement

**Technical Support: 208-462-0626 or [zach@greenfieldwater.com](mailto:zach@greenfieldwater.com)**

