



**GREENFIELD  
WATER SOLUTIONS**

## **AQUAFLEX INSTALL ADDENDUM**



- 1. It is imperative that your installer read the entire AquaFlex manual and this addendum before commencing with the installation process.**
2. Your AquaFlex and copper by-pass harness assembly will arrive In one box.
3. Your second box will contain your Copper Vortexer and NaturalSof

4. After having installed the AquaFlex with the copper by-pass assembly, the Copper Vortexer will be attached onto the **inlet** of the by-pass assembly and the NaturalSof descaler will be attached onto the **outlet** of the by-pass assembly.
5. After the system has been installed and plumbed into the main water supply, install only the GAC bulk filter into stage 2 and (also stage 3 if ordered with a GAC bulk filter for stage 3), leaving all other filter housings empty for the purpose of flushing fines out of the filter. After 5 minutes of flushing, the other filters can be installed and the entire system flushed once more for 5 minutes.
6. Filter Installation Order: *(stages 2 & 3 filter configuration may vary depending on water quality)*

Stage 1: 20 Micron Sediment filter

Stage 2: Pentek GAC Filter

Stage 3: Pentek Iron Filter

Stage 4: Pentek FloPlus .5 micron Filter

#### **INLINE VORTEXER TIPS**

- Installs onto any water supply line up to 1”
- Outfitted with either 3/4” or 1” threaded end fittings.
- Bi-directional flow
- Install vertically or horizontally
- Maintenance free
- Never needs replacement

**Technical Support: 208-462-0626 or zach@greenfieldwater.com**

