



**GREENFIELD  
WATER SOLUTIONS**

## **WHOLE HOUSE VORTEXER INSTALLATION INSTRUCTIONS**

Your Inline Copper Vortexer is designed for installation onto your residential water supply line measuring up to 1”.

Your Inline Copper Vortexer is bi-directional and can be installed where the water line enters your home and before or after any other filtering components

These instructions are according to typical plumbing methods. Actual installations should be adapted to individual requirements and regional codes. We have made every effort to ensure accuracy and reliability of the information, instructions, and directions. However, the manufacturer will not accept responsibility for misinterpretation of the directions or human error.

1. Locate the water service line and turn off the water service line.
2. Open a nearby water spigot and leave open until water stops flowing to ensure water valve is completely turned off, then shut off spigot.
3. The Inline Vortexer is outfitted with standard pipe thread male fittings on each end.
4. Follow standard plumbing procedures to install.
5. Be sure the Vortexer is securely attached in place to the surface it is affixed to using pipe straps or other appropriate means.



6. Turn on the water service supply line slowly and inspect the unit installation to ensure there are no leaks, turn on a nearby water spigot to purge air out of the water line until water runs smoothly all the burping has stopped, then close spigot & check for leaks again.

7. Your Inline Vortexer is now installed and will provide you with many years of faithful service without additional expense, parts replacement or filter changes

For questions and assistance email us at:

[info@greenfieldwater.com](mailto:info@greenfieldwater.com) or text us at 208-462-0626

---